



**This Bath Cabinet Is Designed For:**

- Surface mounted installation in a left-or right-hand corner
1. Determine location of cabinet on wall and mark wall through upper mounting holes. Generally, the accepted height of a mirrored bath cabinet is 64" from the floor to the center of the mirror area. Shorter or taller families may want to adjust this to a more comfortable height.
  2. Draw a horizontal line connecting the wall marks. This line must be level and, if necessary, should be adjusted by using a carpenter's level. Do not assume that the plaster corner is plumb or straight.
  3. Drill mounting holes into studs. Secure to wall with screws (provided) through holes in back of cabinet. If studs are not available, use 3/16" molly bolts or 3/16" wall anchors (not provided), depending upon wall material.
  4. Drill additional mounting holes at top of others rear wall and secure to wall (repeat Step 3).